

VAL-u Line® Series – Printer Driven (24V) Drawers Setup Sheet



Instructions

STEP 1

Prepare a location for the cash drawer by selecting a secured and leveled surface that is no smaller than the cash drawer.

STEP 2

Remove any packaging tape or guards from the currency till.

STEP 3

Connect one side of the corresponding printer-specific MMF RJ-12 Kwick Kable™ to the cable jack located under the cash drawer.

The end of the cable that has a label with the MMF cable part number will plug into the Cash Drawer and the end that has a label that reads: "Connect to Printer" plugs into the receipt printer.

STEP 4

Follow the setup instructions and set proper open codes from the printer manufacturer's manual to properly connect the cash drawer to the receipt printer.



Troubleshooting

If cash drawer does not open electronically, check the following:

- MMF's printer-driven cash drawers connect directly to a receipt printer. This connection requires the POS application to send the proper opening codes to the printer, which will then send the signal to open the cash drawer. Consult the documentation or manuals for your particular printer for the proper open codes.
- Confirm the correct end of the MMF RJ-12 Kwick Kable™ is connected to the cash drawer as well as the printer.
- Verify correct position of the lock. The lock must be in the 12 o'clock position to open electronically.
- Verify Baud Rate, Parity, Data Bits and Stop Bits are set correctly for your software. Baud Rate should be set between 110-9600.
- To manually open the drawer without keys, flip the drawer upside down, glide the leveler located on the bottom-back side of the drawer to release the locking mechanism.

Warning/Safety Instructions

- Avoid breaking coin rolls on the drawer's front panel of the currency tray.
- Lubricate the slides and latch mechanism periodically. Do not clean roller bearings or slides with any water or substance cleaners; use a lint-free fabric to wipe old grease and/or debris.

Content

- 1 Drawer with keyed lock (2 keys supplied*)
- 1 Currency till with removable coin tray

NOTE: RJ-12 Kwick Kable™ printer cables are sold separately

Applicable Part Numbers

MMF-VL1616E-XX	<ul style="list-style-type: none"> • 16"W x 16"D x 4.3"H • 2 media slots • 5 bill/8 coin till • Color: Black matte or white
MMF-VL1616CE-04	<ul style="list-style-type: none"> • 16"W x 13"D x 4"H • 2 media slots • 4 bill/8 coin till • Color: Black matte
MMF-VAL1416E-XX	<ul style="list-style-type: none"> • 14"W x 16"D x 4"H • 2 media slots • 4 bill/5 coin till • Metal bill weights • Color: Black matte or white
MMF-VAL1313E-XX	<ul style="list-style-type: none"> • 13"W x 13"D x 4"H • 2 media slots • 4 bill/5 coin till • Metal bill weights • Color: Black matte or white

For additional accessories, contact your supplier or visit www.mmfpos.com